


















UNIVERSAL

Transformer Set 24VDC 18W
980910

Transformer Set 24VDC 18W	
Adapter 1 - New to DIN	
Adaptor 2 - New to 3,5mm female	
Adaptor 3 - New to 5,5mm female	
Adaptor 4 - 5,5mm male to terminals	
Adaptor 5 - 5,5mm male to 5,5mm male	

Markslojd AB
Granevägen 5 S-511 62 Skene
Sweden
www.markslojd.com



Existing connector on your candle stick	Pictogram existing connector	Combination needed	Comments
New oo connector		Transformer 	
3,5mm male connector		Transformer+Adaptor 2 	
5,5mm male connector		Transformer+Adaptor 3 	
5,5mm female connector		Transformer+Adaptor 3 +Adaptor 5 	
Small round DIN connector		Transformer+Adaptor 1 	
DIN connector to big or other shape		Transformer+Adaptor 1 	cut the plastic of adaptor 1 
OC27 Male connector		Transformer+Adaptor 3 +Adaptor 4 	Cut cable on your candlestick, fix leaderparts in the terminals in adaptor 4 
Other connector		Transformer+Adaptor 3 +Adaptor 4 